McCULLOCH

SERVICE BULLETIN #1116

MODEL **ALL**

DATE **12/5/60**

SUBJECT **EASY METHOD OF REMOVING PITCH FROM CHAIN SAWS**

Some dealers and many users scrape the pitch from the chrome frame of their chain saws with a knife or other sharp tool. While scraping with a knife removes the pitch, the knife can cut into the chrome finish and leave sharp and jagged points. When the chain saw is used these points often dig into the hands and cause cuts. Unless the cuts are promply treated they become infected and take a long time to heal.

Pitch can be removed easily from the chrome frame and other parts of the chain saw with lacquer thinner wiped on with a cloth. After the lacquer thinner has had several minutes to soften the pitch, rub it with the lacquer soaked cloth until the pitch is removed.

COPYRIGHT 1960 McCULLOCH CORPORATION

LITHO IN U.S.A.