McCULLOCH CORPORATION

SERVICE BULLETIN

1515

MODEL: POWER MAC 6A February 22, 1972

SUBJECT: AUTOMATIC OILER INSTRUCTIONS

It is a good practice always to check for proper operation of the automatic oiler system of a new saw or one that has been in storage.

To check operation of the automatic oiler proceed as follows:

1. Prime the oil system by operating the manual oil button.
2. Start the saw and allow it to warm up for a minute or two.
3. Point the tip of the bar at a smooth surface (a piece of cardboard or wood) holding the bar about a foot away from this surface, accelerate the unit to about half throttle and watch for a light spray of oil to appear on the smooth surface.
4. Repeat this procedure after one minute to be sure the oil spray is still present and is the result of automatic oiler operation rather than operation of the manual oiler.

This is a good procedure to follow upon first starting a saw anytime and particularly if the oil tank has run completely out of oil while cutting.

If the check reveals that the automatic system is not working after normal priming, the piston in the automatic oiler is most likely being held by old oil residue which becomes sticky after periods of disuse. Use the following procedure to correct this situation:

1. Protecting the hand with a glove or cloth, rap the manual oiler button sharply.
2. Repeat Steps 3 and 4 above.

McCULLOCH CORPORATION

By Jack Carroll
Service Manager

Copyright 1972 by McCulloch Corporation

LITHO IN U.S.A.