McCULLOCH

SERVICE BULLETIN

NO. 1581

MODEL Mini-Mac, PM 6A, and MAC 10 DATE December 12, 1974

SUBJECT Starter Handle Kit

Starter Handle Kit, P/N 91255, is the new service replacement starter handle on all model saws having Handle, P/N 87851, or Handle, P/N 62190A. The kit contains a starter handle and two washers. The washers have different size inside diameters. The washer with the smaller inside diameter is used on Mini-Mac and PM 6 Models. The washer with the larger inside diameter is used on Mac 10 Models.

To install the new handle and washer proceed as follows:

1. Knot the starter rope between the starter handle and the starter drum.
2. Sever the knot at the end of the starter rope.
3. Remove the old starter handle.
4. Install the new starter handle.
5. Install the washer.
6. Knot the end of the starter rope.
7. Heat the knotted end of the starter rope until a slight melting appears. This prevents fraying of the rope.
   CAUTION: Heat rope end in an area free of combustible materials.
8. Untie the knot tied in step one above.



McCULLOCH CORPORATION

Product Service
Department

Copyright 1974 by McCulloch Corporation

LITHO IN U.S.A.